
## RS-232 to RS-485 Converter CE Model 485PTBR

### **Description**

The 485PTBR converts unbalanced RS-232 signals to balanced, full or half-duplex RS-485 signals. RS-485 is an enhanced version of the RS-422 Standard. It allows multiple drivers and receivers on a two-wire system. The RS-232 port has a female DB-9 connector with pins 2(RD), 3(TD), and 5(SG) supported. Pins 7(RTS) and 8(CTS) are tied together. Also pins 6(DSR), 1(CD), and 4(DTR) are tied together, but not passed through the converter. The RS-485 port has an 8-position pluggable terminal block connector.



#### **Baud Rate**

The 485PTBR can accept baud rates from 300 baud to 115.2K baud. In order to change the baud rate on the 485PTBR a resistor and possibly a capacitor must be changed. By looking up the selected baud rate on Table 1 the resistor and capacitor value can be determined. Remove R3 and C7 from the printed circuit board. Place new components in the R2 and C6 locations. See Figure 1 and 2 for resistor and capacitor locations.

#### Biasing Resistors

The biasing resistors R5 and R7 can also be altered. The 485PTBR comes standard with 4.7K biasing resistors. To change the value of biasing resistors, remove R5 and R7 and replace with new value in locations R4 and R6. See Figure 1 and 2 for resistor locations.

#### **Termination Resistor**

The termination resistor location for the 485PTBR is located at R8. A termination resistor can be placed in the R8 location and a jumper wire placed from the terminal location to RD(B). We recommend a value of 100 to 120 ohm resistor for termination. See Figure 2 for termination resistor location.

#### **Constant Receiver Enable**

The 485PTBR is standard setup with the receiver disabled during transmission. The 485PTBR can be set up for constant receiver enable. When R9 is removed the receiver is in constant receive mode (four-wire). When R9 is in the circuit the 485PTBR is in half-duplex mode (two-wire). See Figure 1 for jumper location.

#### **Data Line Polarity**

The polarity of the two RS-485 lines must be correct. With no data being sent, the RS-232 line should be negative and the RS-485 "A" terminal should be negative with respect to the "B" terminal. If your equipment uses a "+" and "-" naming scheme, in most cases the "A" line will be connected to the "-" and the "B" line will be connected to the "+".

**DECLARATION OF CONFORMITY** 

B&B Electronics Manufacturing Company Manufacturer's Name: Manufacturer's Address: P O Box 1040

707 Dayton Road Ottawa, IL 61350 USA

Model Number: 485PTBR

RS-232 to RS-485 Converter Description: Light industrial ITE equipment Type:

Application of Council Directive: 89/336/EEC

EN 50082-1 (IEC 801-2, IEC 801-3, IEC 801-4) EN 50081-1 (EN 55022, IEC 1000-4-2)

EN 61000 (-4-2, -4-3, -4-4, -4-5, -4-6, -4-8, -4-11)

ENV 50204

Michael J. Fahrion, Director of Engineering

CE

Table 1			
COMPONENT REPLACEMENTS FOR CHANGING BAUD RATE TIMEOUTS			
Baud Rate	Time (ms)	Resistor (R3) (ohm)	Capacitor (C7) (mfd)
300	33.3	330K	0.1
600	16.6	160K	0.1
1200	8.33	820K	0.01
2400	4.16	430K	0.01
4800	2.08	200K	0.01
9600	1.04	100K	0.01
19200	.520	56K	0.01
38400	.260	27K	0.01
57600	.176	16K	0.01
115200	.0868	8.2K	0.01




Figure 1. PC Board Layout - Top





Figure 2. PC Board Layout - Bottom



© 1996 B&B Electronics -- Revised November 2000

This product designed and manufactured in USA of domestic and imported parts by

B & B Electronics Mfg. Co.

707 Dayton Road - P.O. Box 1040 - Ottawa, IL 61350 USA
Phone: (815) 433-5100 - Fax: (815) 433-5105
Home Page: www.bb-elec.com
Sales e-mail: orders@bb-elec.com - Fax: (815) 433-5109
Technical Support e-mail: support@bb-elec.com - Fax: (815) 433-5104

# **B&B** Electronics Ltd

Westlink Commercial Park - Oranmore, Co. Galway - Ireland Phone: +353 91 792444 - Fax: +353 91 792445 Home Page: www.bb-europe.com Sales e-mail: orders@bb-europe.com Technical Support e-mail: support@bb-europe.com