

USER GUIDE
STOX2 Amplifier Unit



Specification:

RS232 interface

9600 baud
8 bit
Parity None
1 Stop Bit

Power supply

8-20V
47 mA in normal operation
8 mA in Power Down

Sync signal


0 V ZERO1 = -0.8V
5 V ZERO1 = 0V

Amplifier

Galvanic isolation
Gain 1.1mV/pA $\pm 30\%$
Offset 240mV $\pm 20\%$
Bandwidth ? Hz
Settle time ? Sec.

PinOut:

Sensor (Impulse) Set fra cylinderens yderside



Pin	1 REF1	Standard -0.8V reference signal
	2 ZERO	Battery powered -0.8V ref. signal, can be turned off by software control.
	3 GUARD	Standard Guard signal, common for all ref signals
	4 SIGNAL	Sensor input signal
	5 REF2	Battery powered -0.8V ref. signal, always on.

Power/Com (Subcom)

Pin	1 GND	(Black)
	2 +8-20Vdc	(White)
	3 Sync Out	(Red)
	4 Tx	(Green)
	5 Rx	(Orange)
	6 Analog sensor Signal	(Blue)
	7 Signal GND (Optional – contact Unisense A/S)	(White/Black)
	8 GND	(Red/Black)

Battery

The unit is equipped with a back up battery, that maintains a constant reference voltage on ZERO1 and REF1 when no power is connected. The battery has an expected lifetime of 10 years, when no current is drawn from the outputs. Contact Unisense A/S for replacement.

SW interface

