PO Box 518 620 Applegate St. Philomath, OR 97370



(541) 929-5650 Fax (541) 929-5277 www.wetlabs.com

Chlorophyll WETStar Characterization

Date: February 4, 2010 S/N: WS3S-942P

Chlorophyll concentration expressed in µg/l can be derived using the equation:

CHL(µg/I) = Scale Factor x (Output - Clean Water Offset)

Analog output

Clean Water Offset (CWO) 0.060 V @

Scale Factor (SF) 14.7 µg/l/V @

Maximum Output 5.50 V @ Resolution 0.46 mV

Ambient Characterization Temperature 22 ± 1°C

Current Draw 40 mA @ 12V (typical)

12-hour Stability 0.34 mV/hr Temperature Stability, 25–2 °C 0.15 mV/°C

Definitions:

CWO: Clean Water Offset value obtained using pure filtered de-ionized water.

SF: Scale Factor is used to convert the fluorescence response of the instrument into chlorophyll-a concentration. Scale Factor is determined at WET Labs during a cross calibration using a solid fluorescent standard and a reference fluorometer whose chlorophyll fluorescence response has been characterized in a laboratory using a mono-species lab culture of *Thalassiosira weissflogii* phytoplankton.

Maximum Output: Maximum signal output of the fluorometer.

Resolution: Standard deviation of 1 minute of clean water data, sampled once per second.

Ambient Characterization Temperature: Room temperature at time of characterization.

Current Draw: The amount of current the instrument uses for operation.

12-hour Stability: Deviation of output averaged over 12 hours.

Temperature Stability: Measured output variation per degree.