PO Box 518 620 Applegate St. Philomath, OR 97370



(541) 929-5650 Fax (541) 929-5277 www.wetlabs.com

C-Star Repair Report

Date 11/16/2010

Customer

Oregon State University

S/N# CST-1031DR

Work order 10505

Standard Service

- · Cleaned meter
- Replaced all seals
- · Focused and aligned optics
- Performed noise test: 1 sample/sec for 60 sec
- · Performed stability test: 1 sample/min for 12 hrs
- · Performed temperature test
- · Performed water calibration
- · Shake-tested unit
- · Pressure-tested unit
- · Updated unit's calibration sheet

Additional Repairs

- Replaced the main body and cover plate because of damage. Pictures included on CD.
- Replaced the electronic board because of damage from main body leak.
- Replaced the fatigued bulkhead connector with the new style 6-pin connector.
- Replaced the LED to use with new electronic board.

Comments

• The new board has a similar analog output as the old board. Note the differences in the Vair and Vdark signals. The new board provides a digital output too. If you have any questions, refer to the User's Guide or contact us at your convenience.

cst-1031dr wkbk.xls Revision L 6/9/09